
## **Remote Control Manual**

## Manual of remote controller:



Mode	Function	Speed of motor	Content
A1	AUTO	1-9	Red & Yellow on, motor moves slowly to speed
A2			Green & Purple on , motor moves slowly to speed
A3			Bule & White on, motor moves slowly to speed
A4			6-color changing, motor moves slowly to speed
A5			7-color changing, motor moves slowly to speed
A6			Color changing slowly 1, motor moves slowly to speedy, no strobe
A7			Color changing slowly 2 motor moves slowly to speedy and strobe
S1	SOUND	0-20	In sound, color change, blasting flash model
S2			Sound , color change, the dynamic model
S3			Sound, color change, lyrical model
STOP START	PAUSE START		Through this button pause and restart
FLASH	FLASH		Automatic flash explosion, through the key - + key blasting flash speed can be adjusted
DMX	BOOT OFF		Through the keys into the DMX mode and exit the DMX mode
- +	FLASH SPEED MOTOR SPEED		Through this keys to adjust motor rotation speed and the critical speed

## Attention:

1 Please read these operating instructions carefully to familiarize you with basic operations of this unit BEFORE USE 2 Without permitted, it is prohibited to spread the contents of this manual to others

3 This manual is only to provide related information, and the contents of this manual will be changed at any time

without notice.

4 Unless the instructions have already stated, please do not freely modified the unit.

## Safety Tips:

- 1 Before installation and maintenance, Please confirm the power is OFF make sure that the ventilation around the unit is good.
- 2 The lighting is designed for indoor demonstration, Please do not use this product in a wet environment for long-term
- 3 The use and maintenance of this, unit should avoid contact with water when using it outdoor, Please take waterproofing measures.
- 4 Person who to take the installation operation and maintenance must be familiar with the lighting, performance. most of the damage is resulted from unfamiliar with its performance..
- 5 Please do not face up to the luminous unit for a long time so as not to cause discomfort to your eyes
- 6 Please often wipe the light with a clean cloth.